



QUICK REFERENCE GUIDE

FUNCTIONS OF REMOTE

Open button: Opens door

Close button: Closes door

Stop button: Immediately stops any door function and allows you to open or close the door without the remote operation. To begin manual mode, turn auto-close knob to OFF position on the back of motor housing

Lock button: Locks door and overrides the auto-release function when auto-release is in ON mode.

Remote load function: Press the up and stop button simultaneously on the remote and wall mount receiver to override the door's auto-close feature. The door will remain open until you press down arrow

CONTROL BOX AND FEATURES

Learn button: Syncs the remotes with the controller board

Setup button: Sets soft stop to protect door system (memorizes travel distance of door)

Auto close knob: Sets the time from when the door is opened until it automatically closes

Auto release knob: Clutch will be released and the door can be opened by hand

Current knob: Allows you to adjust the force with which the door opens and closes

LED indicator light: Displays whether the system is working correctly

Bluetooth: If equipped with Bluetooth module, you may open and close door using a compatible smart phone (only iPhone and Android devices).